




## When should I consider replacing my KELLY Disc Chains?


You should consider replacing your KELLY Disc Chains when they are no longer performing the desired outcome they were originally purchased for. KELLY Disc Chains are considered to be wear items and it's reasonable to expect that these parts may need to be replaced over time.



CL1 Disc Chain



K4 Disc Chain



CL2 Disc Chain

KELLY recommends replacing K4, CL1, W36 & R300 Disc Chains when they are worn to the bottom of the KELLY logo, or 125mm (4.9 inches) from the centre of the discs. For CL2 Disc Chains, KELLY recommends replacement when they are worn to 140mm (5.5 inches) from the centre of the discs. Recommended wear is indicated by the red line in the images.

## How do I purchase new KELLY Disc Chain?

Visit [kellytillage.com/contact/](https://kellytillage.com/contact/) or scan the below QR code to find your local KELLY Representative or Dealer.



KEFL017eu - C - 23102023



Phone +61 8 8667 2253  
Email [sales@kellytillage.com](mailto:sales@kellytillage.com)  
[kellytillage.com](https://kellytillage.com)

Booleroo (Head Office)  
684 Kelly Road,  
Booleroo Centre SA 5482

Adelaide Office  
28 Greenhill Road,  
Wayville SA 5034

