

## **Recommended Maintenance Checklist**

Item to check	First operation	Daily	Weekly	Pre- season
Hydraulic hose and cylinders for damage and oil leaks	<b>✓</b>	<b>√</b>		V
Airline leaks and hose damage *	<b>✓</b>	<b>√</b>		<b>√</b>
Loose or missing fasteners/split pins	<b>✓</b>	<b>✓</b>		<b>✓</b>
Check bushes, pivot and cylinder pins for wear and replace as necessary				V
Wing pivot pins are fitted with retaining pins/bolts	<b>✓</b>	V		<b>✓</b>
Swivel unit fasteners	<b>✓</b>	<b>√</b>		<b>✓</b>
Swivel unit - free and smooth rotation		<b>V</b>	<b>√</b>	<b>V</b>
Swivel unit temperature: Average operating temperature is 55 °C, Failure is indicated at +80 °C	<b>✓</b>	<b>√</b>		V
Tyres are inflated to correct pressure	<b>✓</b>	<b>V</b>	<b>√</b>	<b>V</b>
Wheel nuts are tightened at correct torque	<b>✓</b>			V
Check wheel bearings	<b>V</b>	<b>V</b>	<b>√</b>	V
Check and tighten dust caps	~		<b>✓</b>	<b>V</b>
Tow hitch bolts are tightened at correct torque	<b>V</b>			<b>V</b>
Tow hitch retaining pins are present	<b>✓</b>	<b>V</b>	<b>√</b>	V
Disc roll pins/ locking bolts are in place	<b>✓</b>			V
Chain is tensioned correctly	<b>✓</b>	<b>V</b>		V
Grease wheel bearings				V
Grease wheel arm frame (2006 ONLY)			<b>√</b>	<b>V</b>



Item to check	First operation	Daily	Weekly	Pre- season
Grease wheel lift bush *			<b>&gt;</b>	<b>√</b>
Grease centre cylinder pins x 2			V	<b>V</b>
Grease jockey wheel *			V	<b>V</b>
Grease wing chain tensioner threads *			<b>V</b>	<b>V</b>
Grease wing hinge pins x 8			V	<b>V</b>
Lights are working correctly *	<b>✓</b>	V		<b>V</b>
Warning signs are attached	<b>✓</b>	V		V

Kelly recommends that swivel units are covered during storage to prevent water penetration.

kellytillage.com

Version F

<sup>\*</sup> If fitted to your machine